

WATERLESS URINAL

Daily cleaning instructions

- Remove any rubbish matter from the urinal (snuff, chewing gum, etc.).
- Remove the microbial capsule and check that the capsule contains green solids. If the microbial capsule is completely empty of the solids (the empty capsule, is much lighter, picture below) replace the new microbial capsule after cleaning the urinal.
- Spray the waterless urinal microbial detergent on the inside and outside of the urinal and on the floor in front of the urinal.
- Wash and rinse the urinal well, using clean water.
- Put the microbial capsule in place and spray the inside of the urinal and the the floor with a small amount of microbial detergent.

NB! Other toilet facilities and surfaces can be washed also with a microbial detergent.



The microbial capsule contains green solids.

The microbial capsule is empty, replace it with a new one.